

REPLACING THE COIN STOP KNOB

Please Note: It is common for the pin holes in the Shaft and Knob to be out of alignment, especially on older machines. If this is the case, it will be necessary for the machine to be sent in to us to drill out the holes, or possibly replace the Shaft.

1. You may wish to remove the metal Coin Gauge Cover while doing this procedure.
2. The Coin Stop Knob is located on the front middle of the machine. It is the knob you turn to change from 20-40-C-50-25 count, and press to release the Coin Stop when wrapping coins. Turn the Knob to the 50 setting.
3. The Coin Stop Knob is held on by a 1/16" pin. Take a 1/16" punch and lightly tap the pin out of the hole. PLEASE NOTE: If you have difficulty with the pin, it may be necessary to tap it with more force, but be careful, as you can bend the shaft.
4. Once the pin is out, the Knob should slide straight up off the shaft. It may be necessary to use pliers to work the Knob up off the shaft. It may also be a good idea to clean the shaft once the old Knob is removed.
5. Slide the new Knob onto the shaft, and align the hole in the knob with the hole in the shaft. It is possible that the holes in the Knob and Shaft do not line up, especially with older machines. If this is the case, the Machine would need to be sent back to us to re-drill the holes, or possibly replace the Shaft.
6. Once the holes are aligned, the Pin must be tapped through to secure the Knob. It can be tricky to keep the Knob in place while tapping the Pin; trial and error may be necessary to complete this step.

Please call if you have any questions.

Thank you,

KLOPP International, Inc.
251 Dunbar Avenue
PO Box 985
Oldsmar, FL 34677-0985
E-mail: sales@kloppcoin.com
Toll Free: 1-800-356-9080
Tel: 813/855-6789 Ext. 12
Fax: 813/854-3069
<http://www.kloppcoin.com>